

Wiring for Damper Actuators and Control Valves

July 2011





Wiring for Damper Actuators and Control Valves

General Wiring Instructions

WARNING: The wiring technician must be trained and experienced with electronic circuits. Disconnect power supply before attempting any wiring connections or changes. Make all connections in accordance with wiring diagrams and follow all applicable local and national codes. Provide disconnect and overload protection as required. Use copper, twisted pair, conductors only. If using electrical conduit, the attachment to the actuator must be made with flexible conduit.

Always read the controller manufacturer's installation literature carefully before making any connections. Follow all instructions in this literature. If you have any questions, contact the controller manufacturer and/or Belimo.

Transformer(s)

Belimo actuators require a 24 VAC Class 2 transformer. The actuator enclosure cannot be opened in the field, there are no parts or components to be replaced or repaired.

- EMC Directive: 2004/108/EC

- Software Class A: Mode of Operation Type 1

- Low Voltage Directive: 2006/95/EC

Example: 3 AF Actuators Supplied, 16 Ga. wire (refer to table on page 3)

350 ft. (allowable wire length) \div 3 actuators = 117 ft. maximum wire run

Typical Transform	ner Sizing	
Actuator Series	Voltage	Required VA Per Actuator
EFB, EFX	24	16
AFB, AFX	24	10
AF	24	10
NFB, NFX	24	9
LF	24	7
TF	24	5
GMB	24	7
AMB / ARB	24	6
NMB	24	6
LMB / LRB	24	3
CMB	24	1.5
AHB	24	4.5
LHB	24	3
LUB	24	3
AMQB	24	26
NMQB	24	23
LMQB	24	23
AHQB	24	23
LHQB	24	23
GK / GKR	24	21
NK	24	22
AHK	24	20

CAUTION: It is good practice to power electronic or digital controllers from a separate power transformer than that used for actuators or other end devices. The power supply design in our actuators and other end devices use half wave rectification. Some controllers use full wave rectification. When these two different types of power supplies are connected to the same power transformer and the DC commons are connected together, a short circuit is created across one of the diodes in the full wave power supply, damaging the controller. Only use a single power transformer to power the controller and actuator if you know the controller power supply uses half wave rectification.

Multiple actuators, one transformer

Multiple actuators may be powered from one transformer provided the following rules are followed:

- The TOTAL current draw of the actuators (VA rating) is less than or equal to the rating of the transformer.
- Polarity on the secondary of the transformer is strictly followed.
 This means that all No. 1 wires from all actuators are connected to the common leg on the transformer and all No. 2 wires from all actuators are connected to the hotleg. Mixing wire No. 1 & 2 on one leg of the transformer will result in erratic operation or failure of the actuator and/or controls.

Multiple actuators, multiple transformers

Multiple actuators positioned by the same control signal may be powered from multiple transformers provided the following rules are followed:

- 1. The transformers are properly sized.
- 2. All No. 1 wires from all actuators are tied together and tied to the negative leg of the control signal. See wiring diagram.

Wire type and wire installation tips

For most installations, 18 or 16 Ga. cable works well with Belimo actuators. Review job requirements and determine whether a plenum or appliance rated cable is appropriate. Use code-approved wire nuts, terminal strips or solderless connectors where wires are joined. It is good practice to run control wires unspliced from the actuator to the controller. If splices are unavoidable, make sure the splice can be reached for possible maintenance. Tape and/or wire-tie the splice to reduce the possibility of the splice being inadvertently pulled apart.

Wire length for actuator installation

Keep power wire runs below the lengths listed in the following tables. If more than one actuator is powered from the same wire run, divide the allowable wire length by the number of actuators to determine the maximum run to any single actuator.



	wire		ΔV		_	_	_
\$			20	18	16	14	12
EF	16			145	225	360	250
AF	10			220	350	250	006
NF	6			250	390	009	1000
LFUS	7			325	200	800	1125
TFUS	2			450	002	1100	1175
GK/ GKR	21			110	165	275	440
NKQ	22	MAX D		105	160	260	420
GM/GR	7	istance b	175	325	200	800	1125
NKQ GM/GR AM/AR	9	MAX Distance between Actuator and Supply (feet)	200	375	009	926	1150
	9	ctuator a	200	375	009	925	1150
NM LM/LR	2	ddnS pu	250	450	200		
M	1.5	ly (feet)	008	1150	1200		
АН	9		200	375	009		
LH	2		250	450	200		
רחייי	2		250	450	002		
TR	-		1100	1200	1400		
AMQ NMQ LMQ AHQ	18		20	125	200	300	200

N40067 - 7/11 - Subject to change. @ Belimo Aircontrols (USA), Inc.

3	က		400	750	1125	1175	
CM	3.5		350	009	1000	1150	
 M	4.5		250	450	200	1125	
 MM	6.5	(feet)	175	325	200	800	1125
AM	7.5	ctuator and Supply (feet)	150	300	450	700	1125
GM	7	ctuator ar	175	325	200	800	1125
TFUS	9	4		375	575	006	1150
NF.UP LFUS TFUS GM	7.5	MAX Distance between /		325	200	800	1125
NFUP	6.5	MAX [375	575	006	1150
AF	+			215	345	545	895
AFUP	8.5			265	415	650	1050
Ш	21			110	165	275	440
	wire gauge		50	18	16	14	12
		D∀	′Λ ()			

Π	3		400	750	1125	1175	
CM	3.5		325	009	1000	1500	
LM	4.5		250	450	200	1125	
NM.:	6.5	(feet)	175	325	200	800	1125
AM	5.7	MAX Distance between Actuator and Supply (feet)	150	300	450	002	1125
GM	2	ctuator a	175	325	009	008	1125
TFUS	9	oetween A		375	275	006	1150
LFUS	2	Distance k		325	200	800	1125
NFUP	9.5	MAX		220	350	250	006
AF.UP AFUS NF.UP LFUS TFUS	11			215	345	545	895
AFUP	18			120	200	300	475
EF	59			08	125	200	310
	wire gauge		20	18	16	14	12
		J∨	′Λ (550			

*Belimo actuators and auxiliary switches are designed as a IEC protection class II, double insulated, and do not require an independent ground wire to earth, unless otherwise indicated in this document

800-543-9038 USA 866-805-7089 CANADA 203-791-8396 LATIN AMERICA / CARIBBEAN



SY5	Amps	6.5	pply (feet)		40	<u> </u>	66	168	250
8Y4	Amps	9	or and Sul		43	02	107	182	271
SY3	Amps	3	een Actuat	22	87	140	214	364	543
SY2	Amps	3	MAX Distance between Actuator and Supply (feel	22	87	140	214	364	543
SY1	Amps	1.8	MAX Dist	92	144	233	357	909	902
		wire gauge		18	16	14	12	10	8
			0	ΑV	54	;			

	SY1	SY2	SY3	SY4	SY5	SY6	SY7	SY8	SY9	SY10	SY11	SY12
	Amps	Amps	Amps	Amps	Amps	Amps	Amps	Amps	Amps	Amps	Amps	Amps
wire gauge	0.5	1	1	1.3	1.5	1.8	3.2	4	3.2	4	3	4
				MAX	Distance	between A	MAX Distance between Actuator and Supply (feet)	d Supply (feet)			
18	1515	758	758	583	505	421	237	189	237	189	253	189
16	2381	1190	1190	916	794	661	372	298	372	298	397	298
14	3846	1923	1923	1479	1282	1068	601	481	601	481	641	481
12	5882	2941	2941	2262	1961	1634	919	735	919	735	980	735
10	10000	2000	2000	3846	3333	2778	1563	1250	1563	1250	1667	1250
8	14925	7463	7463	5741	4975	4146	2332	1866	2332	1866	2488	1866

SY12	Amps	2.2		689	1082	1748	2674	4545	6784
SY11	Amps	1.6		947	1488	2404	3676	6250	9328
SY10	Amps	2		228	1190	1923	2941	2000	7463
8Y9	Amps	1.6	feet)	947	1488	2404	9298	6250	9328
SY8	Amps	2	MAX Distance between Actuator and Supply (feet)	758	1190	1923	2941	2000	7463
SY7	Amps	1.6	Actuator ar	947	1488	2404	3676	6250	9328
SY6	Amps	0.8	between A	1894	2976	4808	7353	12500	18657
SY5	Amps	0.7	(Distance	2165	3401	5495	8403	14286	21322
SY4	Amps	9.0	MA	2525	3968	6410	9804	16667	24876
SY3	Amps	0.5		3030	4762	7692	11765	20000	29851
SY2	Amps	0.5		3030	4762	7692	11765	20000	29851
SY1	Amps	0.3		5051	7937	12821	19608	33333	49751
		wire gauge		18	16	14	12	10	8
	220 VAC								

The NEC mandates that 24 VAC over 100 VA power requires CLASS 1 wiring conduit. Local codes may vary. Do NOT mix CLASS 1 & CLASS 2 circuits in the same conduit. Generally, 24 VAC actuators over 100 VA should be changed to 120 VAC models.

110 VAC

Wiring for Damper Actuators and Control Valves

On/Off, Spring Return, Electronic Fail-Safe, 24V

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!

Actuators may be connected in parallel. Power consumption and input impedance must be observed.




WARNING

Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.

On/Off



INSTALLATION NOTES

1

Provide overload protection and disconnect as required.



Actuators may also be powered by 24 VDC.



Actuators with plenum rated cable do not have numbers on wires; use color codes instead.



Actuators with appliance cables are numbered.




APPLICATION NOTES




Meets cULus requirements without the need of an electrical ground connection.

On/Off



On/Off



Refer to page 26 for auxiliary switch (-S models) wiring.

Wiring for Damper Actuators and Control Valves

On/Off, Spring Return, 120, 230V and UP



V231_A_11

Actuators: EFB120(-S) EFX120(-S) AFBUP(-S)

NFBUP(-S) NFXUP(-S) LF120(-S) UF120(-S) UF

AFBUP(-S) AFXUP(-S) LF120(-S) US/LF230(-S) US

AF120(-S) US/AF230(-S) US TF120(-S) US

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!

Actuators may be connected in parallel. Power consumption and input impedance must be observed.



WARNING

Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.





TF120(-S) US can be supplied with both 120 VAC and 230 VAC.



UP models and TF120(-S) US uses "L" instead of "H" on #2 wire.



All 120 VAC, 230 VAC and UP actuators use appliance rated cables.



Universal Power Supply (UP) models can be supplied with 24 VAC up to 240 VAC.




APPLICATION NOTES



Meets cULus requirements without the need of an electrical ground connection.

On/Off



Refer to page 26 for auxiliary switch (-S models) wiring.

W232_11

Actuators:

LF24-3(-S) US

TF24-3(-S) US

LFC24-3...US

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!

Actuators may be connected in parallel. Power consumption and input impedance must be observed.




WARNING

Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.


Floating Point



Triac Sink

N40067 - 7/11 - Subject to change.

Belimo Aircontrols (USA), Inc.



Refer to page 26 for auxiliary switch (-S models) wiring.

INSTALLATION NOTES

/3\

Actuators may also be powered by 24 VDC.



Actuators with plenum rated cable do not have numbers on wires; use color codes instead. Actuators with appliance cables are numbered.



Actuators Hot wire must be connected to the control board



For triac sink the Common connection from the actuator must be connected to the Hot connection of the controller. The actuator must be connected to the control board common.




APPLICATION NOTES




Meets cULus requirements without the need of an electrical ground connection.

†	Actuator	Wire Number	Color
	TF24-3 US	4	Org
	TF24-3-S US	5	Org
	LF24-3 US	4	Grn
	LF24-3-S US	5	Wht

Triac Source



Triac Sink with Separate Transformer





332_1

Actuators: LMB24-3(-S) (-P5) (-P10) (-T) TR24-3(-T) US NMB24-3

CMB24-3...

ARB24-3-5

AMB24-3(-S) GMB24-3... GRB24-3-5 LMX24-3(-T) NMX24-3(-T) GRB24-3-7 AMX24-3(-T) GMX24-3... GMB24-3-X1 LRB24-3(-S) ARX24-3 ARB24-3(-S) LRX24-3

LRCB24-3(-S)

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!

Actuators may be connected in parallel. Power consumption and input impedance must be observed.



WARNING

Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.



INSTALLATION NOTES



Actuators may also be powered by 24 VDC.



Actuators with plenum rated cable do not have numbers on wires; use color codes instead. Actuators with appliance cables are numbered.



The TR24-3-T US actuators are provided with a numbered screw terminal strip instead of cable.



TR24-3 US actuators cannot be wired in parallel.




APPLICATION NOTES




Meets cULus requirements without the need of an electrical ground connection.


On/Off




Floating Point



On/Off - SPDT Switch



Floating Point



Refer to page 26 for auxiliary switch (-S models) and -P5, -P10 potentiometer wiring.

N40067 - 7/11 - Subject to change. © Belimo Aircontrols (USA), Inc.

Wiring for Damper Actuators and Control Valves

Floating Point, Electronic Fail-Safe, 24V

7612 1

Actuators: GKB24-3

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!

Actuators may be connected in parallel. Power consumption and input impedance must be observed.



WARNING

Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.

X

INSTALLATION NOTES



Provide overload protection and disconnect as required.



Actuators may also be powered by 24 VDC.



Control signal may be pulsed from either the Hot (source) or the Common (sink) 24 VAC line.



Contact closures A & B also can be triacs. A & B should both be closed for triac source and open for triac sink.



For triac sink the common connection from the actuator must be connected to the hot connection of the controller.




APPLICATION NOTES



Meets cULus requirements without the need of an electrical ground connection.

Floating Point



Wiring for Damper Actuators and Control Valves

On/Off and Floating Point, Non-Spring Return, 100 to 240V



N364_1

Actuators:

LMX120-3 NMX120-3 AMX120-3 GMX120-3 LRX120-3 ARX120-3 CMB120-3

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!

Actuators may be connected in parallel. Power consumption and input impedance must be observed.



WARNING

Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.



INSTALLATION NOTES



LMB(X), NMB(X), AMB(X), GMB(X), LRB(X), and ARB(X) can be supplied with either 120 VAC or 230 VAC.



All 120VAC and 230VAC actuators use appliance rated cables.



Actuators with appliance cables are numbered.




APPLICATION NOTES




Meets cULus requirements without the need of an electrical ground connection.

On/Off



Floating Point



Refer to page 26 for auxiliary switch (-S models) wiring.

N40067 - 7/11 - Subject to change. @ Belimo Aircontrols (USA), Inc.



W233_

Actuators:

EFB24-SR(-S) NFB24-SR(-S) EFX24-SR(-S) NFX24-SR(-S) AFB24-SR(-S) LF24-SR(-S) US AFX24-SR(-S) AF24-SR US TF24-SR(-S) US

AFA24-SR US

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!

Up to four actuators may be connected in parallel if not mechanically linked. Power consumption and input impedance must be observed.




N40067 - 7/11 - Subject to change.

Belimo Aircontrols (USA), Inc.

WARNING

Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.







Actuators may also be powered by 24 VDC.



Actuators with plenum rated cable do not have numbers on wires; use color codes instead. Actuators with appliance cables are numbered.



Only connect common to neg. (-) leg of control circuits.



APPLICATION NOTES



Meets cULus requirements without the need of an electrical ground connection.




A 500 Ω resistor converts the 4 to 20 mA control signal to 2 to 10 VDC.



The AFA24-SR US and TF24-SR(-S) US are supplied without position feedback.

t	Actuator	Wire Number	Color
	EFB24-SR(-S)	5	Org
	EFX24-SR(-S)	5	Org
	AFB24-SR(-S)	5	Org
	AFX24-SR(-S)	5	Org
	AF24-SR US	5	Wht
	NFB24-SR(-S)	5	Org
	NFX24-SR(-S)	5	Org
	LF24-SR US	5	Grn
	LF24-SR-S US	5	Wht



Refer to page 26 for auxiliary switch (-S models) wiring.



W333_11

Actuators: LMB24-SR (-T) NMB24-SR **LMX24-SR (-T)** NMX24-SR (-T) LRB24-SR **TR24-SR (-T) US** AMB24-SR GMB24-SR AMX24-SR (-T) GMX24-SR ARB24-SR LRX24-SR ARX24-SR CMB24-SR-L GKX24-SR NKQB24-SR NKQX24-SR CMB24-SR-R GKB24-SR

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!

Up to four actuators may be connected in parallel if not mechanically linked. Power consumption and input impedance must be observed.



WARNING

Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.



INSTALLATION NOTES



Actuators may also be powered by 24 VDC.



Actuators with plenum rated cable do not have numbers on wires; use color codes instead.

Actuators with appliance cables are numbered.



Only connect common to neg. (–) leg of control circuits. Terminal models (-T) have no-feedback.




APPLICATION NOTES




Meets culus requirements without the need of an electrical ground connection.



A 500 Ω resistor converts the 4 to 20 mA control signal to 2 to 10 VDC.





Wiring for Damper Actuators and Control Valves

Proportional, Non-Spring Return, 100 to 240V

N365 1

Actuators: LMX120-SR

AMX120-SR ARX120-SR

NMX120-SR LRX120-SR

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!


Actuators may be connected in parallel. Power consumption and input impedance must be observed.



WARNING

Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.







LMB(X), NMB(X), AMB(X), GMB(X), LRB(X), and ARB(X) can be supplied with either 120 VAC or 230 VAC.



Only connect common to neg. (–) leg of control circuits.



All 120 VAC and 230 VAC actuators use appliance rated cables.



Actuators with appliance cables are numbered.



APPLICATION NOTES



Meets cULus requirements without the need of an electrical ground connection.



A 500 Ω resistor converts the 4 to 20 mA control signal to 2 to 10 VDC.



W225_2_11

Actuators:

AF24-PC US NMX24-PC LMX24-PC GMX24-PC AMX24-PC ARX24-PC LRX24-PC

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!


Actuators may be connected in parallel. Power consumption and input impedance must be observed.



WARNING

Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.



- * White color wire for AF24-PC US, Pink color for all others.
- ‡ White color wire for AF24-PC US, Orange color for all others.



INSTALLATION NOTES



Actuators may also be powered by 24 VDC.



Actuators with plenum rated cable do not have numbers on wires; use color codes instead. Actuators with appliance cables are numbered.



APPLICATION NOTES



Meets cULus requirements without the need of an electrical ground connection.

N40067 - 7/11 - Subject to change. © Belimo Aircontrols (USA), Inc.

Proportional, Spring Return, 24V, 3 k Ω or 10 k Ω Control Input

W604 1

Actuators: LF24-ECON-R03 US

LF24-ECON-R10 US

AF24-ECON-R03 US

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!

Actuators may be connected in parallel. Power consumption and input impedance must be observed.



WARNING

Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.

INSTALLATION NOTES



Actuators with plenum rated cable do not have numbers on wires; use color codes instead. Actuators with appliance cables are numbered.



Min-position is adjustable from 0 to 100% with a potentiometer on the actuator cover.



A relay or switch can spring return the actuator when the RTU fan de-energizes, or if low ambient temperature is sensed.



A standard relay can be used to close the sensor circuit to engage economizer mode, e.g. outside air changeover device like a dry bulb or enthalpy limit switch. Honeywell® logic module W7459A and enthalpy sensor C7400 also provide terminals for this switching.



A remote CO2 sensor or DDC controller can change the standard relay opening or closing the sensor circuit. This device can be a relay or a dry bulb/enthalpy limit switch.



Override control for Y2 only accepts 0 to 10 VDC override control.


Override Control

N40067 - 7/11 - Subject to change.


Belimo Aircontrols (USA), Inc

Wire	Input Signal	AF24-ECON LF24-ECON position	Application
Y1	24 VAC	Drive closed (0%)	Morning warm-up cycle
Y1	Common	Drive open (100%)	Smoke Purge
Y1	Open wire	Drive to min. position	Mechanical cooling in use, RTU thermostat calls for heat.
Y2	0 VDC to 10 VDC	Min. position of 0% to 100%	Override potentiometer via a remote C02 sensor/controller or DDC controller.

Override



Standard Economizer Mode Wiring



*10 k Ω NTC thermistor for -R10 types.



Actuators: LF24-SR-E US

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!

Actuators may be connected in parallel. Power consumption and input impedance must be observed.



WARNING

Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.



APPLICATION NOTES



Meets cULus requirements without the need of an electrical ground connection.




Provide overload protection and disconnect as required.

Thre	e-Position Contro	ol Signals	
Switch A	Wire 2-Red (x)	Wire 3-White (D)	Position
Open**	Any	Any	Closed (via spring)
Closed	24 VAC	Open	Min-position*
Closed	Open	24 VAC	Full Open*
Closed	24 VAC	24 VAC	Full Open*

- * Desired position achieved by driving actuator with motor.
- ** An example would be to interlock the actuator power supply with the fan motor starter.

2 to 10 VDC Control of LF24-SR-E US



INSTALLATION NOTES



Actuators may also be powered by 24 VDC.



Actuators with plenum rated cable do not have numbers on wires; use color codes instead. Actuators with appliance cables are numbered.



A 500 Ω resister converts the 4 to 20 mA control signal to 2 to 10 VDC.




Min-position is adjustable from 0 to 100% with a potentiometer on the actuator cover.




For three-position control set direction of rotation to CW (default).

Switch A, actuator spring returns when open (e.g., fan interlock).

Three-Position Control with a SPDT Switch or Two Contact Closures (e.g. fan, cooling Y)



Min-Position with Full Open Override (with a single contact closure)





Actuators: NV24-3 US NVD24-3 US NVFD24 (-E) US

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION


Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.




Equipment damage!

Actuators may be connected in parallel. Power consumption and input impedance must be observed.


Floating Point and On/Off Control (diagram shown with default position of S1.2: Off)



On/Off Control (diagram shown with default position of S1.2: Off)



On/Off Control-using actuator to drive one direction and spring the opposite direction. NOTE: A bridge must be made inside the NVF between terminals 2 and 3 (diagram shown with default position of S3.2: 3-way Off, 2-way On)



Λ

WARNING

Live Electrical Components!


During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.




APPLICATION NOTES

Meets cULus requirements without the need of an electrical ground connection.


On/Off Control-using actuator to drive open/close, spring upon power loss. (diagram shown with default position of S3.2: 3-way Off, 2-way On)



Triac Source Floating Point







SPRING RETURN ACTUATORS MODEL DESIGNATION



retracting plunger (spring up)
NVFD24 US
NVFD24-MFT US
NVF24-MFT US



extending plunger (spring down)
NVFD24-E US
NVFD24-MFT-E US
NVF24-MFT-E US



Actuators: NVF24-MFT (-E) US NVFD24-MFT (-E) US NV24-MFT US NVD24-MFT US

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!

Actuators may be connected in parallel. Power consumption and input impedance must be observed.




WARNING


Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.


Floating Point Control. (diagram shown with default position of S3.2: 3-way Off, 2-way On.)



Pulse Width Modulation Control Wiring (diagram shown with default position of S3.2: 3-way Off, 2-way On)



MFT Typical 2 to 10 VDC or 4 to 20 mA Wiring (diagram shown with default position of S3.2: 3-way Off, 2-way On)



INSTALLATION NOTES



For triac sink the Common connection from the actuator must be connected to the Hot connection of the controller. Position feedback cannot be used with a triac sink controller. The actuator internal common reference is not compatible.



APPLICATION NOTES



Meets cULus requirements without the need of an electrical ground connection.




Control signal may be pulsed from either the Hot (Source) or Common (Sink) 24 VAC line.




IN4004 or IN4007 diode. (IN4007 supplied, Belimo part number 40155)

Triac Source Floating Point



Triac Sink Floating Point



SPRING RETURN ACTUATORS MODEL DESIGNATION



retracting plunger (spring up)
NVFD24 US
NVFD24-MFT US
NVF24-MFT US



extending plunger (spring down)
NVFD24-E US
NVFD24-MFT-E US
NVF24-MFT-E US

N40067 - 7/11 - Subject to change.

Belimo Aircontrols (USA), Inc.

WOOR A 1

Actuators: TF24-MFT US LF24-MFT(-S) US

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!

Actuators may be connected in parallel if not mechanically mounted to the same shaft. Power consumption and input impedance must be observed.

\triangle

WARNING


Live Electrical Components!


During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.

Floating Point

N40067 - 7/11 - Subject to change.

Belimo Aircontrols (USA), Inc





1			
T	Actuator	Wire Number	Color
	TF24-MFT US	5	Org
	LF24-MFT US	5	Wht

INSTALLATION NOTES

 $\frac{3}{\Delta}$

Actuators may also be powered by 24 VDC.

<u></u>

Actuators with plenum rated cable do not have numbers on wires; use color codes instead. Actuators with appliance cables are numbered.



Control signal may be pulsed from either the Hot (Source) or Common (Sink) 24 VAC line.



For triac sink the Common connection from the actuator must be connected to the Hot connection of the controller. Position feedback cannot be used with a Triac sink controller. The actuator internal common reference is not compatible.



APPLICATION NOTES

Meets cULus requirements without the need of an electrical ground connection.

 \wedge A 500 Ω resistor co

A 500 Ω resistor converts the 4 to 20 mA control signal to 2 to 10 VDC.




Contact closures A & B also can be triacs. A & B should both be closed for triac source and open for triac sink.




IN4004 or IN4007 diode. (IN4007 supplied, Belimo part number 40155).

Two Position



Override Control to min, mid, max, Positions



Refer to page 26 for auxiliary switch (-S models) wiring.

W400 A 1

Actuators: EFB24-MFT(-S) EFX24-MFT(-S) AFB24-MFT(-S) AFX24-MFT(-S) NFB24-MFT(-S) NFX24-MFT(-S)

LMX LRX NMX AMX ARX GKX NKQ ARX24-MFT-5 ARB24-MFT-5 GRX24-MFT-5

GMX24-MFT-X1 GRB24-MFT-S GRB24-MFT-5 GRB24-MFT-7

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!

Actuators may be connected in parallel if not mechanically mounted to the same shaft. Power consumption and input impedance must be observed.




WARNING


Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.


VDC/4-20 mA



Floating Point (except NKQ)



Triac Source and Sink Diagrams (See page 21)



INSTALLATION NOTES

3

Actuators may also be powered by 24 VDC.

<u>\$</u>

Actuators with plenum rated cable do not have numbers on wires; use color codes instead. Actuators with appliance cables are numbered.



Control signal may be pulsed from either the Hot (Source) or Common (Sink) 24 VAC line.



For triac sink the Common connection from the actuator must be connected to the Hot connection of the controller. Position feedback cannot be used with a triac sink controller. The actuator internal common reference is not compatible.



APPLICATION NOTES

Moote all us requirements with



Meets cULus requirements without the need of an electrical ground connection.




A 500 Ω resistor converts the 4 to 20 mA control signal to 2 to 10 VDC.




Contact closures A & B also can be triacs. A & B should both be closed for triac source and open for triac sink.

Two Position



Override Control to min, mid, max, Positions



800-543-9038 USA



Wiring for Damper Actuators and Control Valves

MFT, Non-Spring Return, 24V

Actuators: LMX LRX **NMX AMX ARX** ARX24-MFT-5 ARB24-MFT-5 **GMX24-MFT** GMX24-MFT-X1 GRX24-MFT-5 GRX24-MFT-7 GRB24-MFT-5

Hazard Identification

GRB24-MFT-7

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!

Actuators may be connected in parallel if not mechanically mounted to the same shaft. Power consumption and input impedance must be observed.




WARNING


Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.

Triac Sink



Triac Source



INSTALLATION NOTES



Actuators with plenum rated cable do not have numbers on wires; use color codes instead. Actuators with appliance cables are numbered.



Only connect common neg (-) leg of control circuits.



For triac sink with common connection from the actuator must be connected to the hot connection of the controller. The actuator must be connected to the control board common.




APPLICATION NOTES



Meets cULus requirements without the need of an electrical ground connection.

Triac Sink with Separate Transformer





Control Type: PWM

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



W234_A_11

Equipment damage!

Actuators may be connected in parallel if not mechanically mounted to the same shaft. Power consumption and input impedance must be observed.



WARNING

Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.

Wiring multiple...MFT actuators to single shaft and/or on valves. All MFT actuators are wired in master-slave configuration.

MFT actuator configurations should also co-ordinate with each other. Meaning the master input = controllers output. Master output = slave input. Slave output = controller input.

Example

Controller	Master	Slave	Slave
Output	Feedback	Input	Feedback
0.1 to 25.5 sec	2 to 10 VDC	2 to 10 VDC	0 to 5 VDC

Multiple Actuators Mounted to One Control Shaft					
Model M	ax. Qty Per Shaf	t Torque Generated			
EFB24-MFT(-S) EFX24-MFT(-S)	3	810 in-lb			
AFB24-MFT(-S) AFX24-MFT(-S)	3	432 in-lb			
GMX(B)24-MFT	2	640 in-lb			
GKX(B)24-MFT	2	640 in-lb			

INSTALLATION NOTES

Actuators may also be powered by 24 VDC.




Actuators with plenum rated cable do not have numbers on wires; use color codes instead. Actuators with appliance cables are numbered.



Control signal may be pulsed from either the Hot or Common 24 VAC line.

Pulse Width Modulation



N40067 - 7/11 - Subject to change. © Belimo Aircontrols (USA), Inc



Wiring for Damper Actuators and Control Valves

Spring Return and Non-Spring Return, 24V for use with Honeywell® Electronic Series 90, or a 0 to 135 Ω input

Actuators: AFB24-MFT95

AFX24-MFT95

GMX24-MFT95

AMX24-MFT95

NMX24-MFT95

LMX24-MFT95

Wnew60408_

INSTALLATION NOTES



Actuators with plenum rated cable do not have numbers on wires; use color codes instead. Actuators with appliance cables are numbered.



Provide overload protection and disconnect as required.



Actuators and controller must have separate transformers.



Consult controller instruction data for more detailed information.



Resistor value depends on the type of controller and the number of actuators. No resistor is used for one actuator. Honeywell® resistor kits may also be used.




To reverse control rotation, use the reversing switch.


Wire Colors

1 = Black 3 = White 5 = Gray 2 = Red 4 = Pink 6 = Orange


Override




The direction of rotation switch is set so that the fail safe position and the position of the damper is closed with no signal at wire R.




Low Limit Control




High Limit Control




Wiring Multiple Actuators to a Series 90 Controller




Wiring Multiple Actuators to a Series 90 Controller using a Minimum Position Potentiometer



Typical wiring diagrams for multiple actuators used with the W973, W7100 and T775 controllers



Used with the W973 and W7100 controllers



800-543-9038 USA



Actuators: LF24-MFT-20 US LF24-MFT-S-20 US

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!

Actuators may be connected in parallel. Power consumption and input impedance must be observed.



WARNING

Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.




INSTALLATION NOTES

3

Actuators may also be powered by 24 VDC


Provide overload protection and disconnect as required.

Typical Control Wiring for MP-52XX Series Actuators to Controllers Requiring External 20 VDC Power Supply




Green, Ground

6 to 9 VDC Control of LF24-MFT (-S) -20 US



Multiple LF24-MFT (-S) -20 US Actuators from One Controller



Refer to page 26 for auxiliary switch (-S models) wiring.

N40067 - 7/11 - Subject to change. @ Belimo Aircontrols (USA), Inc.

internal SPDT auxiliary switch.



W234_

Control Type: VDC or 4-20mA MFT95

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!

Actuators may be connected in parallel if not mechanically mounted to the same shaft. Power consumption and input impedance must be observed.



WARNING

Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.

INSTALLATION NOTES



Actuators may also be powered by 24 VDC.



Actuators with plenum rated cable do not have numbers on wires; use color codes instead. Actuators with appliance cables are numbered.



Provide overload protection and disconnect as required.



Consult controller instruction data for more detailed information.



To reverse control rotation, use the reversing switch.

Wiring multiple...MFT actuators to single shaft and/or on valves. All MFT actuators are wired in master-slave configuration.


MFT actuator configurations should also co-ordinate with each other. Meaning the master input = controllers output. Master output = slave input. Slave output = controller input.

Example


Controller	Master	Slave	Slave
Output	Feedback	Input	Feedback
2 to 10 VDC	2 to 10 VDC	2 to 10 VDC	0 to 5 VDC

Multiple Actuators Mounted to One Control Shaft					
Model	Max. Qty Per Shaf	t Torque Generated			
EFB24-MFT(-S) EFX24-MFT(-S)	3	810 in-lb			
AFB24-MFT(-S) AFX24-MFT(-S)	3	432 in-lb			
GMX(B)24-MFT	2	640 in-lb			
GKX(B)24-MFT	2	640 in-lb			

VDC or 4-20mA



Multiple Actuators Mounted to One Control Shaft



W224_A_11

EFX...-S AFB...-S AFX...-S AF...-S US NFB...-S NFX...-S LF...-S US TF...-S US Actuators: EFB...-S

AMB(X)...-S LMB(X)...-S ARB(X)...-S LRB(X)...-S **S1A/S2A** LMB(X)...(-P5)(-P10)



INSTALLATION NOTES

One built-in auxiliary switch (1xSPDT), for end position indication, interlock control, fan startúp, etc.

/13\

Two built-in auxiliary switches (2xSPDT), for end position indication, interlock control, fan startup, etc.




WARNING


Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.


Auxiliary Switch Wiring for EFB...-S, EFX...-S, AFB...-S,



Auxiliary Switch Wiring for AF... -S US



Add on Auxiliary Switches S1A/S2A for GMB(X), AMB(X), NMB(X), LMB(X), GRB(X), ARB(X), NRB(X), LRB(X)




APPLICATION NOTES



Meets cULus requirements without the need of an electrical ground connection.

Same voltage must be used for dual switch models. Either 24 VAC or line voltage, not both.


Auxiliary Switch Wiring for LF...-S US, TF...-S, LMB(X)24-3-S, AMB(X)24-3-S, LRB(X)24-3-S, ARB(X)24-3-S



Auxiliary Switch Ratings

Product	Voltage	Resistive Load	Inductive Load
EFBS, EFXS	250	3.0 A	0.5 A
AFBS, AFXS	250	3.0 A	0.5 A
AFS US	250	7.0 A	2.5 A
NFBS, NFXS	250	3.0 A	0.5 A
LFS US	250	3.0 A	0.5 A
TFS US	250	3.0 A	0.5 A
AMB(X)S	250	3.0 A	0.5 A
LMB(X)S	250	3.0 A	0.5 A
ARB(X)S	250	3.0 A	0.5 A
LRB(X)S	250	3.0 A	0.5 A
S1A, S2A	250	3.0 A	0.5 A

Potentiometer and Auxiliary Switch Wiring for LMB(X)24-3(-S)(-P5)(-P10)



N40067 - 7/11 - Subject to change. © Belimo Aircontrols (USA), Inc





Actuators: SYx-MFT




Notes:

- 1. Motor CAMS have been factory calibrated and should not be moved.
- 2. An adaption must be performed if any limit switch is adjusted. This will calibrate the beginning and end stopping points. Press the adaption button for 3 seconds and release.





N40067 - 7/11 - Subject to change. © Belimo Aircontrols (USA), Inc.





Sensitivity switch setting is position #3 for factory default. To widen deadband, select a higher number (up to 9).



Notes:


- 1. Do not change sensitivity or dip switch settings with power applied!
- 2. VR1 and VR2 are factory calibrated and should not be moved.
- 3. Motor CAMS have been factory calibrated and should not be moved.

Dip **Switch Settings**



INPUT = 2-10 VDC






INPUT = 1-5 VDC




OUTPUT = 4-20mA



OUTPUT = 2-10 VDC



RESPONSE = DIRECT



RESPONSE = REVERSE



LOSS OF SIGNAL = CLOSED (Direct Acting)



LOSS OF SIGNAL = OPEN (Reverse Acting)



LOSS OF SIGNAL = OPEN (Direct Acting)



LOSS OF SIGNAL = CLOSED (Reverse Acting)





Potentiometer (Factory Pre-set)

For 2-position actuators with 1k feedback option

Potentiometer points 1, 2, 3 are wired to terminal blocks 8, 9, 10. **→** 1k Ω

When a valve is closed: 9, 10 \longrightarrow 0k Ω

When a valve is opened: 8, 9 \longrightarrow 0k Ω 9, 10 \longrightarrow 1k Ω


For modulating actuators with 1k feedback option*


Potentiometer points 1, 2, 3 are wired to terminal blocks 8, 9, 10.

When a valve is closed:

8, 9 \longrightarrow 1k Ω

When a valve is opened:





actuators DO NOT master/slave using optional potentiometer.

*On modulating

Ground

SY Actuator Wiring Diagram, SY1...5-24V - On/Off SY1...12-120V or 230V On/Off

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

Indicates an action or condition that may cause irreversible damage to the actuator(s) or associated equipment.

Equipment damage!

Power consumption and input impedance must be observed.

NOTES SY1...5-24



Each actuator should be powered by a single, isolated control transformer.

- · Isolation relays must be used in parallel connection of multiple actuators using a common control signal input.
- "H" cannot be connected to terminal #3 and #4 simultaneously.
- Required: Terminal #7 needs to be field wired to enable heater circuit.





Observe class 1 and class 2 wiring restrictions.


Transformer sizing = SY actuator draw X 1.25 (safety margin) (Ex. SY2-24 requires 3.0A x 1.25 = 3.75A, 3.75A X 24 VAC = 90VA Transformer).

NOTES SY1...12-120V or 230V

- · Caution: Power Supply Voltage
- Isolation relays must be used in parallel connection of multiple actuators using a common control signal input.
- "H" (L2) cannot be connected to terminal #3 and #4 simultaneously.
- Required: Terminal #7 needs to be field wired to enable heater circuit.







W547 1

SY Actuator Wiring Diagram, SY1-24P and SY1-110P (220P)

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

Indicates an action or condition that may cause irreversible damage to the actuator(s) or associated equipment.

Equipment damage!

Power consumption and input impedance must be observed.



NOTES SY1...24P

Each actuator should be powered by a single, isolated control transformer.

- Power supply Com/Neutral and Control Signal "—" wiring to a common is prohibited. Terminals 4 and 6 need to be wired separately.
- Do not change sensitivity or dip switch settings with power applied.



Observe Class 1 and Class 2 wiring restrictions.

Transformer sizing = SY actuator draw X 1.25 (safety margin) (Ex. SY2-24 requires 3.0A x 1.25 = 3.75A, 3.75A X 24 VAC = 90VA Transformer)



APPLICATION NOTES



Ground shielded wire at control panel chassis. Tape back ground at actuator.





Use of feedback is optional.



NOTES SY1...110P (220P)

- Caution: Power supply voltage.
- Power supply Com/Neutral and Control Signal "—" wiring to a common is prohibited. Terminals 4 and 6 need to be wired separately.
- · Do not change sensitivity or dip switch settings with power applied.





N40067 - 7/11 - Subject to change.

Belimo Aircontrols (USA), Inc.



W547_2_11

Actuator:

SY2...5-24MFT

SY2...12-120MFT

SY2...12-230MFT

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

Indicates an action or condition that may cause irreversible damage to the actuator(s) or associated equipment.

Equipment damage!

Power consumption and input impedance must be observed.

NOTES SY2...5-24MFT

Each actuator should be powered by a single, isolated

• Power supply Com/Neutral and Control Signal "-" wiring to a common is prohibited.



Observe Class 1 and Class 2 wiring restrictions.

Transformer sizing = SY actuator draw X 1.25 (safety margin) (Ex. SY2-24 requires $3.04 \times 1.25 = 3.754, 3.754 \times 24 \text{ VAC} = 90\text{VA Transformer}$)



APPLICATION NOTES




Ground shielded wire at control panel chassis. Tape back ground at actuator.

36 Use of feedback is optional.



· Caution: Power supply voltage.



N40067 - 7/11 - Subject to change. © Belimo Aircontrols (USA), Inc.

SY Actuator Wiring Diagram, SY1...5-24 – Multiple Wiring SY1...12-110 (220) – Multiple Wiring

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

N549_11

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices

Indicates an action or condition that may cause irreversible damage to the actuator(s) or associated equipment.

Equipment damage!

Power consumption and input impedance must be observed.

24V AC Transformer G Ground Line (K1) Voltage 3 4 Closed 5 HTR LS3 В A-C (Open Indication C n 1.54 D-F (Closed Indication) Contact Rating: 5A 250 VAC SY2...5-24 Actuator A G Ground Common 3 Open 4 Closed 5 6 HTR The isolation relays may not be needed. Dependent on signal LS3 В C D LS4 Ε D-F (Closed Indication Contact Rating: 5A 250 VAC Ma. В SY2...5-24 A-B (Open Indication)

A-E (Closed Indication)

SY1-110 (220)


INSTALLATION NOTES

Observe class 1 and class 2 wiring restrictions.

Transformer sizing = SY actuator draw X 1.25 (safety margin) (Ex. SY2-24 requires 3.0A x 1.25 = 3.75A, 3.75A X 24 VAC = 90VA Transformer).

⚠ NOTES

- Caution: Power Supply Voltage.
- Isolation relays must be used in parallel connection of multiple actuators using a common control signal input.
- "H" (L2) cannot be connected to terminal #3 and #4 simultaneously.
- Required: Terminal #7 needs to be field wired to enable heater circuit.



N40067 - 7/11 - Subject to change. @ Belimo Aircontrols (USA), Inc.

SY1 Contact Arrangements

ing: 5A 125 VAC Ma: 3A 250 VAC Ma:

LS4 •

SY1 -24

E

F

W550 1

SY Actuator Wiring Diagram, SY1-24P - Multiple Wiring

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

Indicates an action or condition that may cause irreversible damage to the actuator(s) or associated equipment.

Equipment damage! Power consumption and input impedance must be observed.



Observe class 1 and class 2 wiring restrictions.

Transformer sizing = SY actuator draw X 1.25 (safety margin) (Ex. SY2-24 requires 3.0A x 1.25 = 3.75A, 3.75A X 24 VAC = 90VA Transformer).



NOTES SY1-24P

Each actuator should be powered by a single, isolated control transformer.

- SY1-24P notes: Power supply Com/Neutral and Control Signal
 "-" wiring to a common is prohibited. Terminals 4 and 6 need to
 be wired separately otherwise irreversible damage will occur.
- Do not change sensitivity or dip switch settings with power applied.




APPLICATION NOTES



Recommended twisted shielded pair for control wiring. Ground shielded wire at control panel chassis. Tape back ground at actuator.



Use of feedback is optional.





Actuators: SY2...5-24MFT

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

Indicates an action or condition that may cause irreversible damage to the actuator(s) or associated equipment.

Equipment damage! Power consumption and input impedance must be observed.

INSTALLATION NOTES

Observe class 1 and class 2 wiring restrictions.

Transformer sizing = SY actuator draw X 1.25 (safety margin) (Ex. SY2-24 requires 3.0A x 1.25 = 3.75A, 3.75A X 24 VAC = 90VA Transformer).



NOTES SY2...5-24MFT



Each actuator should be powered by a single, isolated control transformer.




APPLICATION NOTES



Recommended twisted shielded pair for control wiring. Ground shielded wire at control panel chassis. Tape back ground at actuator.



Use of feedback is optional.



W552_1_11

Actuators: SY1-110P SY1-220P

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

Indicates an action or condition that may cause irreversible damage to the actuator(s) or associated equipment.

Equipment damage! Power consumption and input impedance must be observed.



Observe class 1 and class 2 wiring restrictions.



APPLICATION NOTES



Recommended twisted shielded pair for control wiring. Ground shielded wire at control panel chassis. Tape back ground at actuator.




Use of feedback is optional.



NOTES SY1-110P (220P)

- Caution: Power supply voltage.
- Do not change sensitivity or dip switch settings with power applied.





WARS C

Actuators: SY2...12-120MFT SY2...12-230MFT

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

Indicates an action or condition that may cause irreversible damage to the actuator(s) or associated equipment.

Equipment damage! Power consumption and input impedance must be observed.



Observe class 1 and class 2 wiring restrictions.



APPLICATION NOTES



Recommended twisted shielded pair for control wiring. Ground shielded wire at control panel chassis.

Tape back ground at actuator.




Use of feedback is optional.



NOTES SY2...12-120MFT (230MFT)

· Caution: Power supply voltage.




N40067 - 7/11 - Subject to change.

Belimo Aircontrols (USA), Inc.



Actuators: ZONE 24NC ZONE24NO ZONE24NC-S ZONE24NO-S ZONE120NO ZONE120NO

ZONE120NC-S ZONE120NO-S



Built-in Auxiliary Switch (optional) (-S models)

Actuators: FSLF120(-S) US FSAF24(-S) US FSLF24(-S) US FSN

FSNF120(-S) US

FSNF24(-S) US

FSAF120(-S) US

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!

Actuators may be connected in parallel. Power consumption and input impedance must be observed.



Equipment damage!

Actuators may be connected in parallel if not mechanically linked. Power consumption and input impedance must be observed.


[7


APPLICATION NOTES



Meets cULus requirements without the need of an electrical ground connection.

All • on this page indicates • f • manual reset high temperature limit or relay.





INSTALLATION NOTES

Actuators may also be powered by 24 VDC.



Two built-in auxiliary switches (2xSPDT), for end position indication, interlock control, fan startup, etc.



Provide overload protection and disconnect as required.




S4 makes to S6 when the actuator is powered open.




Double insulated.




Two built-in auxiliary switches (2xSPST), for end position indication, interlock control, fan startup, etc.



Auxiliary Switch Wiring for FSLF24-S US, FSLF120-S US



Auxiliary Switch Wiring for FSNF24-S US, FSNF120-S US





511 11

Actuators: FSAF24-BAL (-S) US FSAF24-SR US

Hazard Identification

Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Equipment damage!

Actuators may be connected in parallel if not mechanically mounted to the same shaft. Power consumption and input impedance must be observed.



Equipment damage!

Actuators may be connected in parallel if not mechanically linked. Power consumption and input impedance must be observed.



APPLICATION NOTES



Meets cULus or UL requirements without the need of an electrical ground connection.



INSTALLATION NOTES



Actuators may also be powered by 24 VDC.



Only connect common neg (-) leg of control circuits.



A 500 Ω resister converts the 4 to 20 mA control signal to 2 to 10 VDC.



Two built-in auxiliary switches (2xSPDT), for end position indication, interlock control, fan startup, etc.



Provide overload protection and disconnect as required.




Only connect Hot, Wire 2 to Wire 3 override controls.




Double Insulated

All $\bullet \bullet$ on this page indicates $\bullet \lnot \bullet$ manual reset high temperature limit or relay.


Auxiliary Switch Wiring for FSAF24-S US, FSAF120-S US




Auxiliary Switch Wiring for FSAF24-BAL-S US, FSAF24-SR-S US



Balancing Control Fire and Smoke



Proportional Control Fire and Smoke







SA

BELIMO

ACR Supply Company Inc.

4040 S. Alston Avenue Durham, NC 27713 Phone: 919-765-8081 With branches in NC

Aireco Supply

9120 Washington Boulevard Savage, MD 20763-0414 Phone: 301-953-8800 With branches in MD, VA

Amcon Controls, Inc.

11906 Warfield Street San Antonio,TX 78216 Phone: 210-349-6161

Houston, TX branch 713-464-7002 Mandeville, LA branch 985-624-3303

Applied Automation

A Wilson Mohr Company 3186 South Washington Street, #230 Salt Lake City LIT 84115

Salt Lake City, UT 84115 Phone: 801-486-6454

Boston Aircontrols, Inc.

8 Blanchard Road Burlington, MA 01803 Phone: 781-272-5800

Charles D. Jones Co.

445 Bryant Street, Unit #1 Denver, CO 80204-4800 Phone: 800-777-0910

With branches in CO, MO, KS

Climatic Control Div/ICD

5061 W. State Street Milwaukee, WI 53208 Phone: 800-242-1656 With branches in WI

Cochrane Supply and Engineering, Inc.

30303 Stephenson Highway Madison Heights, MI 48071-1633

Phone: 800-482-4894

With branches in MI and Maumee, OH

Columbus Temperature Control

1053 E. 5th Avenue Columbus, OH 43201 Phone: 800-837-1837

Controlco 985 3rd Street

Oakland, CA 94607 Phone: 510-636-7900 With branches in CA, NV

Control Products

9101 Jameel, Suite 130 Houston, TX 77447 Phone: 713-849-7200

Edward C. Smyers & Co.

223 Fort Pitt Boulevard Pittsburgh, PA 15222-1505 Phone: 412-471-3222

Engineered Control Systems

4805 N.W. 79th Avenue

Suite 11

Miami, FL 33166 Phone: 305-418-8901 With branches in FL G & O Thermal Supply

5435 N. Northwest Highway Chicago, IL 60630 Phone: 773-763-1300 With branches in IL

Industrial Controls Distributors LLC

1776 Bloomsbury Avenue Wanamassa, NJ 07712 Phone: 800-631-2112 With branches in

GA, KY, IN, MA, ME, NC, NY, OH, PA, TN

Interstate HVAC Controls

30 Vineland Street Brighton, MA 02135 Phone: 617-782-9000

Jackson Controls

1708 E. 10th Street Indianapolis, IN 46201 Phone: 317-231-2200

M & M Controls

9E West Aylesbury Road Timonium, MD 21093 Phone: 410-252-1221

With a branch in Alexandria, VA

MICONTROLS, Inc.

6516 5th Place South Seattle, WA 98124 Phone: 800-877-8026 With branches in WA, OR

Meier Supply

123 Brown Street Johnson City, NY 13790 Phone: 607-797-7700 With branches in NY, PA

Minvalco, Inc.

3340 Gorham Avenue Minneapolis, MN 55426-4267 Phone: 952-920-0131 With branches in MN

RSD/Refrigeration Supply Distribution

26021 Atlantic Ocean Drive Lake Forest, CA 92630 Phone: 949-380-7878 With branches in

CA, NV, OR, AK, AZ, ID, UT, WA, MT

Saint Louis Boiler Supply, Co.

617 Hanley Industrial Court St. Louis, MO 63144 Phone: 314-962-9242

South Side Control Supply, Co.

488 N. Milwaukee Avenue Chicago, IL 60610-3923 Phone: 312-226-4900 With branches in IL, IN

Stromquist and Company

4620 Atlanta Road Smyrna, GA 30080 Phone: 404-794-3440

With a branch in Orlando, FL

Temperature Control Systems

10315 Brockwood Road Dallas, TX 75238 Phone: 214-343-1444 With branches in OK, TX Tower Equipment Co., Inc.

1320 West Broad Street Stratford, CT 06615 Phone: 800-346-4647

Twinco Supply Corporation

55 Craven Street

Huntington Station, NY 11746-2143 Phone: 800-794-3188

With branches in NY

Wilson-Mohr, Inc.

12610 West Airport Blvd, Suite 100

Sugarland, TX 77478 Phone: 281-295-8850

For a complete list of distributors

in Canada, please visit our website: www.belimo.ca or call toll free: 866-805-7089

For a complete list of distributors in Latin America and the Caribbean, please visit our website: www.belimo.us

or call: 203-791-8396

-ATIN AMERICA AND THE CARIBBEAN

Belimo worldwide: www.belimo.com

BELIMO Americas

USA Locations, 43 Old Ridgebury Road, Danbury, CT 06810 Tel. 800-543-9038, Fax 800-228-8283, marketing@us.belimo.com

1049 Fortunado Loop, Sparks, NV 89436 Tel. 800 987-9042, Fax 800-987-8875, marketing@us.belimo.com

Canada Locations, 14/16 - 5716 Coopers Avenue, Mississauga, Ontario L4Z 2E8 Tel. 866-805-7089, Fax 905-712-3124, marketing@us.belimo.com

Latin America and the Caribbean Customer Service, Tel. 203-791-8396, Fax 203-791-9139, marketing@us.belimo.com

